

<b>Fuse</b>	<b>Value</b>	<b>Outputs</b>
<b>F1</b>	<b>8,0 AT</b>	X6: Ignition
		X7: Auger 2
		X8: Ash discharge
		X9: Heat exchanger cleaning
<b>F2</b>	<b>10,0 AT</b>	X10: Stoker auger forward
		X11: Stoker auger backward
		X12: Dosing auger
		X13: Auger 1
<b>F3</b>	<b>1,0 AT</b>	X14: Suctuion cup
		X15: Primary air
<b>F4</b>	<b>2,5 AT</b>	X16: Secondary air
		X17: three port valve open/close
		X18: Bypass pump
<b>F5</b>	<b>1,0 AT</b>	X19: TÜB-Hupe
<b>F6</b>	<b>0,4 AT</b>	X20: Flue gas fan
<b>F7</b>	<b>2,5 AT</b>	Fues primary side of transformer T1 (230 VAC)
<b>F8</b>	<b>2,5 AT</b>	Fuse for secondary side of transformer T1 (18 VAC)
		Fues for secondary side of transformer T1 (12 VAC/Lambda probe)