



➤	OPERATING PANEL	CONTROL MODE	
0	● ● ● ● ●	PROPORTIONAL PRESSURE AUTO ADAPT	⏏
1	● ● ● ● ●	CONSTANT PRESSURE AUTO ADAPT	⏏
2	● ● ● ● ●	PROPORTIONAL PRESSURE 1	⏏
3	● ● ● ● ●	PROPORTIONAL PRESSURE 2	⏏
4	● ● ● ● ●	PROPORTIONAL PRESSURE 3 - MAX	⏏
5	● ● ● ● ●	CONSTANT PRESSURE 1	⏏
6	● ● ● ● ●	CONSTANT PRESSURE 2	⏏
7	● ● ● ● ●	CONSTANT PRESSURE 3 - MAX	⏏
8	● ● ● ● ●	CONSTANT CURVE 1	⏏
9	● ● ● ● ●	CONSTANT CURVE 2	⏏
10	● ● ● ● ●	CONSTANT CURVE 3 - MAX	⏏

➤	OPERATING PANEL	CONTROL MODE	
0	● ● ● ● ●	PROPORTIONAL PRESSURE AUTO ADAPT	⏏
1	● ● ● ● ●	CONSTANT PRESSURE AUTO ADAPT	⏏
2	● ● ● ● ●	PROPORTIONAL PRESSURE 1	⏏
3	● ● ● ● ●	PROPORTIONAL PRESSURE 2	⏏
4	● ● ● ● ●	PROPORTIONAL PRESSURE 3 - MAX	⏏
5	● ● ● ● ●	CONSTANT PRESSURE 1	⏏
6	● ● ● ● ●	CONSTANT PRESSURE 2	⏏
7	● ● ● ● ●	CONSTANT PRESSURE 3 - MAX	⏏
8	● ● ● ● ●	CONSTANT CURVE 1	⏏
9	● ● ● ● ●	CONSTANT CURVE 2	⏏
10	● ● ● ● ●	CONSTANT CURVE 3 - MAX	⏏